

1. Remove as much foam gasket tape as possible.
2. Install rubber gasket up to the step in the plastic.
3. Re-assemble Die to Brake.

