

Open the lower door located on the front of the game to access the programming buttons

Press and hold the test button for five seconds to enter the programming menu, then use the down button to navigate to system settings menu and press test.

	PRIL 23, 2021 01:27:13 PM	SERIAL #. CABINET TYPE: N/		NOPOLY RSION 1.44	APRIL 23, 01:27:49		SI CABINET T
MAIN MI	ENU		S	YSTE	M SET		NGS
DIAGNOSTICS				TE & TIME	04/8	23/2021	
RICING & PAYOUT				GION/LANGL	JAGE USA (GEN	7:49 PM	
YSTEM SET		Verify or diagnose the		CKET MECHS			
DLUME		operation of all game functions.	BE	ZEL SIZE		40	Set the dat
JITS			LA	NDING POSIT	TION	1170	and time.
TS TIES			MD	NITOR CONF	IG TOP RIGHT B	NOTTOM	
STEM INFORMAT	ION	CURRENT	MEI	GA MARQUEE M		RIGHT	
		SETTINGS	MED	A MARQUEE LEC		0	
XIT		SWIPES COST PER GAME: \$1.00	MA	CHINE ID	LINK DISA	LED	CURRENT
		TICKET VALUE: \$0.01000 EST. TICKETS PER GAME: 40					SETTINGS
Navigation: Vol +/-		40	EXI	IT			URRENCY INPUT: C SWIPES
lect Item: Test Back: Service						TI	COST PER GAME: \$1. CKET VALUE: \$0.01 IT. TICKETS PER GA

Using the down button scroll down to monitor config, pressing test will display the available options to rotate the monitors. Use the up and down buttons to highlight the appropriate option and press test to select it. Please note to get the lower monitor to turn on you must exit the menu back to game mode.

