

Error 8 : Indicates home sensor failure.

- The home sensors are the same as the score sensor.
- Power for the sensor is daisy chained through the last sensor in the chain.
- Grey/Brown wire is the output of the home sensor which is tied to the adjacent sensor.
- The home sense line goes back to the I/O board to connector P4, pin 3.
- The sense line should be at +5 volts when not blocked.
- The sense line should drop to 0volts when blocked.

