

# **RT Flash Creator**

## **User Manual**

**JTN**  
**©2016 Raw Thrills, Inc.**


# Index

Creating A Flash Drive Installer.....	3
Adding and Removing Games.....	9
Using Flash Installers.....	14
Updating The Flash Install Creator.....	19
Compatible Games and PCs.....	24

# **Creating A Flash Drive Installer**

# Creating A Flash Drive Installer

## Step: 1



Select the game you would like to create an installer for from the drop down menu.  
Then click the 'Next' button to continue.

## Step: 2




Disconnect all flash drives you want to make into installers, from your computer.

Click the 'Next' button to continue.

# Creating A Flash Drive Installer

## Step: 3



Plug-in each flash drive you want to turn into an installer.

As the program detects each drive, an info box will appear listing information about the drive.

Once all of the drives you want to turn into installers have appeared, click the 'Next' button to continue.

Note: The program will only recognize up-to 10 drives at a time

# Creating A Flash Drive Installer


## Step: 4



A warning screen will appear, informing you that each of the drives listed will be completely erased.

Click the 'Next' button to continue.

## Step: 5





The flash drives are now being turned into installers.  
This process may take a while.

When complete you will automatically be taken to the next screen.

# Creating A Flash Drive Installer

## Step: 6



This screen displays the results of the Flash Creator.  
If a drive was successfully turned into an installer it will be Green.  
If a drive failed to be turned into in an installer it will appear Red.

Success: Green || Failed: Red

## Step: 7



Remove all flash drives you turned into installers from you computer.

# Creating A Flash Drive Installer

**Step: 8**

**DONE!**

# **Adding and Removing Games**


# Adding and Removing Games

## Step: 1

Plug in the Flash Drive installer you would like to add or remove games from.

**Note: The flash drive must have previously been setup using the Flash Creator Program**



## Step: 2



In a Windows Explorer window, navigate to the flash drive. You should see 2 folders, “boot” & “porteus”, as well as the .ISO files of the game you installed with the creator.

# Adding and Removing Games



## Step: 3 Adding Games



To add a game to the drive simply copy all the ISOs of the desired game to this section of the flash drive. An easy way to this is to simply drag and drop the ISO file.

# Adding and Removing Games


## Step: 4 Removing Games



To remove a game, simply delete all the ISOs of the game you wish to remove, from the flash drive. A quick way to delete an ISO is to click on it and press the delete key.

# Adding and Removing Games

## Step: 5



Once you have finished adding and removing games, safely eject the flash drive from the computer by right clicking on the drive in the left hand column, and selecting “Eject” from the menu.

## Step: 6

**DONE!**

# Using Flash Installers

# Using Flash Installers


## Step: 1



Plug the flash drive into the PC you wish to update. Then power-cycle the machine.

# Using Flash Installers

## Step: 2




After a few seconds a menu such as the one shown above should appear.


Note: If the computer boots normally and the menu above does not appear the PC's BIOS settings may be incorrectly setup. Contact your service provider for further assistance.

# Using Flash Installers

## Step: 3




Navigate to and select the game you want install. You can either use the buttons inside of the coin door or a keyboard, to navigate the menu. The controls are displayed on the right hand side of the screen.



By default the service buttons are displayed, however if the RIO is not detected or a key press from a keyboard is detected, the keyboard controls will be displayed instead.

# Using Flash Installers

## Step: 4



A confirmation message will appear on screen. Confirm you want to install the game, and the installation will begin.


## Step: 5

**DONE!**

# Updating The Flash Install Creator


# Updating The Flash Install Creator

## Step: 1




In the top left-hand corner of the window, select 'File' → 'Update Installer'.

## Step: 2



Click on the “Select Update File” button.

## Step: 3




Navigate to the location of the Flash Installer Update file you wish to use.  
Select the file and click open.

The update file will be named "Flash\_Installer\_Update\_###.7z" where the # will be replaced with numbers. (ex. Flash\_Installer\_Update\_1.0.0.7z)

# Updating The Flash Install Creator

## Step: 4




If the file selected is a valid update file, the version number of the update will be displayed and the “Update” button will be enabled.

Click the “Update” button to finish updating.

# Updating The Flash Install Creator

## Step: 5



Once the update has finished, you will see a “Result” line which will inform you if the update was successful or not.

## Step: 6

**DONE!**

# **Compatible Games and PCs**

# Compatible Games and PCs

## Raw Thrills Flash Drive Installer Compatibility Sheet

<b>Compatible Games</b>	
<b>Raw Thrills</b>	<b>Play Mechanix</b>
Super Alpine Racer	Aliens Armageddon
Batman	Big Buck Hunter HD
Doodle Jump	Moto GP
Galaga Assault	Terminator Salvation
Jurassic Park	
Pacman Chomp Mania	<b>Bumble Bear Games</b>
Pixar Cars	Killer Queen
Super Bikes 2	
Super Cars	
SnoCross	
World's Largest Pacman	

<b>Compatible PCs</b>
<b>Dell</b>
Optiplex 390
Optiplex 3010
Optiplex 3020
Optiplex 3050
<b>HP</b>
6005
6305
705

### Notes:

- Any Raw Thrills game release 2016 or later is compatible**
- Any Play Mechanix game released 2017 or later is compatible**
- Any PC released 2016 or later is compatible**