


37Hz



- Span should be set at 1000mm —move the carriage so that the end of it is positioned 1000mm from the center of the pulley;

