
How to identify which sensors you have.


Determine the sensors installed for the Goalie slide. There are two types of sensors used in the goalie slide assembly, fine focus and wide beam.

Please follow the steps below to determine which sensor you have in your game and advise service which one you have installed.


Step 1:




Step 2:



Located at the floor are two sensors that are aimed up. These sensors reflect off the glide rail. The goalie has reflective tape at the bottom. When the goalie is over a sensor, you will see either a very focused red dot or a wide circle that fills most of the reflector. Move goalie over each sensor to see





WIDE FOCUS